



# CR-007

Fastening Systems

Parts #	Code 1	Code 2	Description
1	460001	00824/3 - 20	Housing
2	460102	00835/0 - 31	Special pin
3	460103	06128/3 - 44	Special pin spring
4	460104	00836/7 - 32	Special pin sleeve
5	460205	00829/2 - 25	Thumb wheel
6	460206	00820/0 - 26	Regulating screw
7	301013	10123/8 - 110	Steel ball
8	460207	08785/0 - 96	Compression spring
9	460208	00801/1 - 79	Data plate
10	461001	00740/1 - 3	Steel liner
11	461005	00810/2 - 39	Regulating pin
12	461006	08665/2 - 105	Allen cap screw
13	461100	00741/9 - 8	Silencer assembly
14	461110	00812/8 - 99	O ring
15	461111	00804/5 - 22	Jacket
16	462000	00728/6 - 4	Piston guide assy.
17	462001	00815/2 - 62	Pressure pin
18	452002	00814/4 - 72	Retaining ring
19	452200	00748/4 - 5	Piston assembly
20	452220	00884/7 - 73	Piston ring
21	453000	00729/4 - 6	Fastener guide assy.
22	453021	00855/7 - 45	Stop ring
23	453022	00856/5 - 80	Retaining ring
24	453123	00858/1 - 59	Pressure spring
25	453124	00853/2 - 58	Fastener detent
26	464001	00803/7 - 41	Firing pin spring
27	464002	00827/6 - 29	Spring guide
28	464003	00828/4 - 35	Nut
29	464100	00739/3 - 10	Firing pin assembly
30	450005	00825/0 - 23	Trigger
31	465101	00823/5 - 64	Release lever
32	465102	00839/1 - 65	Dowel pin
33	465103	00822/7 - 47	Holder
34	465104	00837/5 - 33	Magazine detent
35	465105	00869/8 - 61	Detent spring
36	465106	00639/6 - 109	Dowel pin

Parts #	Code 1	Code 2	Description
37	465107	00841/5 - 97	Self tapping screw
38	465208	00826/8 - 27	Sear
39	465209	00810/9 - 24	Sear holder
40	465210	00833/4 - 43	Tension spring
41	465211	00784/9 - 51	Special screw
42	467001	00834/2 - 21	Rubber grip
43	467002	00832/6 - 30	Support strip
44	467003	19103/1 - 104	Allen cap screw
45	467004	00831/8 - 34	Retention plate
46	468001	00731/0 - 7	Cocking lever assy.
47	468100	00963/9 - 9	Connector assembly
48	468102	00950/6 - 50	Swivel pin
49	458154	00807/3 - 42	Tension spring
50	468201	00805/2 - 36	Transport lever
51	468202	00808/6 - 28	Special screw
52	458257	00811/0 - 98	Screw
53	458259	00806/0 - 37	Leaf spring
54	468203	00880/5 - 38	Cover plate
55	458300	00678/3 - 13	Cocking lever
56	458363	00865/6 - 53	Disc
57	458364	70491/5 - 100	Compression spring
58	458365	00873/0 - 108	Circlip
59	458389	00870/6 - 76	Fastener symbol
60	458400	00862/3 - 46	Cocking grip assy.
61	458466	00869/8 - 67	Friction pin
62	458467	n/a	Blocking plate
63	458468	00372/2 - 101	Compression spring
64	458500	00897/9 - 12	Ram assembly
65	468301	00816/9 - 69	Baseplate
66	458074	00865/4 - 56	Threaded pin
67	458075	n/a	Link
68	458076	n/a	Special pin
69	458077	00949/8 - 68	Swivel pin
70	450081	00783/1 - 48	Circlip
71	no picture	n/a	Cleaning kit
72	no picture	n/a	Plastic case
73	n/a	00854/0 - 60	Pivot pin